UM-SJTU JI VE215 Lab#1

We will test some properties of DC circuits in this lab.

- Please hand in your post-lab assignment before the due date. Please do
 your post-lab assignment following the requirements in each problem.
 Both hand-written and printed are accepted.
- You are encouraged to print this lab manual and then finish the post-lab questions on it. For pictures or diagrams, you may print it in a paper, cut it down and paste on this worksheet.

Instruments

DC power supply (Agilent E3631A or MOTECH LPS 305)


Multi-meter

Resistors of 50Ω and 100Ω

Light-Emitting Diode (LED)

Breadboard and Wires

Instruments Introduction



For breadboards, the picture above shows its inner structure. The nodes

represent the pin-hole and the blue lines represent the metal wires hidden inside the board.


For multi-meters, please rotate the knob from "off" to the required function (including DC current, DC voltage, resistance, AC current, AC voltage) with the proper measuring range according to your measurement.

- For DC voltage measurement, please rotate the knob of multi-meter from "off" to " \(\overline{V} \) (or \(\overline{mV} \))" and connect the two ports in parallel with the element to be measured.
- For DC current measurement, please rotate the knob of multi-meter from "off" to " \(\overline{A} \) (or \(\overline{mA} \))" and connect it in series with the element to be measured, in other words, please connect it directly inside the circuit.
- For resistance measurement, please rotate the knob of multi-meter from "off" to "Ω" and connect the element to be measured in parallel with the multi-meter independently. Caution: Please do not measure the resistance of elements when it's connected in the circuit otherwise the result will be disturbed.

Mention that for some categories of multi-meters, you need to press the "scale" button if changing the measurement scale. Please try it and contact the TAs for help for any problems.

Problem #1 Basic Circuit Theory

Please connect the following circuit on your breadboard.



Please set the DC power supply V_{DC} to 3V and then open it. Then, please measure the values of I_1 , I_2 , I_3 , V_1 and V_2 using multi-meter and complete the following table:

Notations	I ₁	I ₂	IBENA	V ₁	V ₂
Values	35.44 mp	22.99m/f	1000	1.795	1.1960

Please do not break your circuit since we will use the same circuit in the next problem

Post-Lab Questions for (P1)

(1) What's the relationship among I_1 , I_2 and I_3 according to your measurement? Which circuit law could be verified based on that result?

(2) What's the relationship among V_{DC} , V_1 and V_2 according to your measurement? Which circuit law could be verified based on that result?


(3) What's the value of I_2/I_3 according to your measurement? How can the result verify the current division law of the parallel connected resistors?

(4) What's the value of V_1/V_2 according to your measurement? How can the result verify the voltage division law of the series connected resistors?

$$\frac{V_1}{V_2} = 1.501$$
 $PR = 5011 | w = \frac{100}{3}$
 $\frac{R_1}{R_2} = \frac{3}{2} = 1.5$
 $\frac{V_1}{R_2} = \frac{V_1}{R_2} = \frac{V_2}{R_2}$

Problem #2 Ohm's Law

Please use the same circuit as your problem 1.




Please set the DC power supply V_{DC} to 1V, 2V, 3V, 4V, 5V and measure the values of I_2 & V_2 corresponding to each V_{DC} . Please complete the following table during your experiment.

Source Voltage V _{DC}	I ₂	V_2	
1V	7278mg	0.388·v	
2V	15.56mA	0.800 V	
3V	23.61mA	1. 200 V	
4V	31. 50mA	Lobonv	
5V	39.39mA	1.999V	


Post-Lab Questions for (P2)

(1) Please plot the curve of V_2 and I_2 . Explain: How can this curve verify the Ohm's law?



Problem #3 Non Linear Circuit

Please connect the following circuit on your breadboard.



Please set the DC power supply V_{DC} to 1.0V, 1.2V, 1.4V,


1.6V... 2.8V and 3.0V and measure the values of $\ I_D\ \&\ V_D$ corresponding to each $\ V_{DC}.$

Please complete the table next page during your experiment.

Source Voltage V	_{DC} I _D	\mathbf{v}_{D}
1.0V	0.0MA	0.748V: 1.5
1.2V	0.0MA	U-9001/20
1.4V	O.INA	1.0500.144
1.6V	AM8.8	1-2004 /6
1.8V (0.45mA	(-3524 LT)
2.0V >	.54ma 9.96/mg	L445V.1-87
	5-30mA 10 93mA	1.64441-9.7
2.4V 8	36mg 11.79.MA	1.78001-97
2.6V	5 AM 1 2. 3 MMA	1-8624 2,00
2.8V	1479mA 12 66mA	1-9204 5-3X
3.0V	18-d9mA1 2-95mH	1962 7 2.07

Post-Lab Questions for (P3)

(1) Please plot the curve of V_D and I_D . Is this LED a linear circuit element based on the curve you obtained? Why?



No. Because the image is not a straight & line.

(2) What's the purpose of connecting the 50Ω resistor in series with the LED? What will happen if we do not connect it?

Due to too large circuit it may be boken.

Post-Lab Reflection Question

- (1) Is your experimental result the same as your analysis (Need data as proof)? If not, how do you interpret this difference? What do you think is the source of the experimental error?
- (2) What do you learn from this experiment? (e.g. what experimental procedures, how to debug, etc.)

(1) Basicary, yes.

in P1(1), Ix13=34.64mA

I1=35.44mA It is quitecluse

in P((2) V1+V2=2.991V

Voc-3V It is also quite close.

The minor difference may be consect by the bad contact or the hard touching the ammeter or reading before fully stabilising

70 debug,
121. Use the emacter or the
electric meter to measure the
clota step by step, mesh by nesh to final
References out the bug.

[1] Circuits Make Sense, Alexander Ganago, Department of Electrical Engineering and Computer Science, University of Michigan, Ann Arbor.

In the field of experimental procedures,

I learnt to the basic connectioning with DC

source and bread wards. Also, to message
(like resistance)
the for better connection, something can be
phagged into the breadhood for the metan
to touch.